





## Audio Capture Filter




## Video Capture Filter






### Video Capture Pin



### Video Preview Pin



### Video Crossbar



## TVTuner

**Eigenschaften** ✖

TV-Tunereigenschaftenseite

<b>Kanal</b> 33 <input type="button" value="1"/> <input type="button" value="2"/> <input type="button" value="3"/> <input type="button" value="4"/> <input type="button" value="5"/> <input type="button" value="6"/> <input type="button" value="7"/> <input type="button" value="8"/> <input type="button" value="9"/> <input type="button" value="0"/> <input type="button" value="Eingabe"/> <input type="button" value="AutoTune"/>	<b>Land/Region</b> 43	<b>Tunerbereich</b> 0	<b>Tunermodus</b> TV
<b>Status</b> Locked	<b>Videostandardwerte</b> PAL_B NTSC_M		
<b>Eingang</b> <input checked="" type="radio"/> 1 <input type="radio"/> Antenne <input type="radio"/> 2 <input type="radio"/> 3 <input checked="" type="radio"/> Kabel	<b>Frequenz</b> Video: 103250000 Audio: 108750000		

## TV Audio

**Eigenschaften** ✖

TVAudio

TV Audio Mode

<b>Channels</b> <input type="radio"/> Mono <input checked="" type="radio"/> Stereo	<b>Language</b> <input type="radio"/> Language A <input type="radio"/> Language B <input type="radio"/> Language C
--	---

